



1. 部品表・金具表により、数を確認してください。組み立ての際はかならず2人以上でおこなってください。
2. 天板(A)を平らな場所に、裏面を上にして置いてください。
この際、天板(A)に傷がつかないようにカーペットやラグなどのやわらかい素材を下に敷いて作業してください。
3. 脚(B)を十字に組み立てます。(図1参照)




4. 組み立てた脚(B)を天板(A)に固定します。
六角セムス(イ)を8ヶ所に取り付け、ドライバーで締めてください。
5. 最後に、片方の脚に過度の荷重がかからないよう脚を床から持ち上げてテーブルを起したら完成です。






注意


- 使用中に天板の揺れがある場合は、六角セムス(イ)を増し締めしてください。
- 組み立て後、ガタツキがある場合は、脚先のアジャスターを回し調整を行ってください。
- テーブルの上には絶対に乗らないでください。破損の原因になります。
- 形状が異なっても、組み立て方法は同様です。

部品表		金具表	
(A) 天板	1		(イ) 六角セムス 8
(B) 脚	2		




Assembly Instructions

1. Please ensure all parts are included by referring to the parts list. Always assemble with at least two people.
2. Place the top panel (A) upside down on a flat surface. Make sure to place a carpet or soft rug underneath to prevent scratches.
3. Assemble the legs (B) in an X shape. (Diagram 1)



4. Secure the assembled legs (B) to the top panel (A). Insert the hex bolts (C) into the 8 locations and tighten them with a screwdriver.
5. Finally, lift the table by raising it from the legs to avoid putting excessive load on one leg.





Important Notes

- In case the top panel is unstable during use, re-tighten the hex bolts (C).
- If the table wobbles after assembly, adjust the level by turning the adjusters at the ends of the legs.
- Do not stand on the table. This may cause damage.

The assembly procedure is the same regardless of the shape.

Parts List		Fittings List	
(A) Top Panel	1		(C) Hex Bolts 8
(B) Leg	2		

